










# SMS FLATSCREEN CL ST







Contents			
A.	Pillar		1
B.	Ceiling plate		1
C.	Plastic Cap		1
D.	Tilt		1
E.	Screws M8x20		2
F.	Nuts		2
G.	Screws M5X20		4
H.	Safety Screw		1
I.	Vesa Plate 75X75 / 100X100		1
J.	Screws M4X20+M4X10+washer		4+4+4
K.	Cables		2
L.	Plastic cover (over cables)		1
M.	Allen Keys		3
N.	Flat Screen ( Not included )		
O.	Ceiling Screws(Not included)		
P.	Screw Driver ( Not included )		




4




5




6



7



8



9

