




ASSEMBLY ROLLING RISE










For Further Assistance:



ASSEMBLY ROLLING RISE




For Further Assistance:

1.800.948.0344

sales@maclocks.com








For Further Assistance:

1.800.948.0344

sales@maclocks.com



ROLLING RISE HEIGHT ADJUSTMENTS



For Further Assistance:


1.800.948.0344

sales@maclocks.com

OVE-




LOCKING AND UNLOCKING THE CASTERS







ENCLOSURE INSTALLATION



PAGE 6 OF 6