



# MINI/BATT

## PowerGOO WIRELESS CHARGER + POWER BANK 6000 mAh



Please register online  
[www.miniBatt.com/register](http://www.miniBatt.com/register)

**Qi**  
Qi-compatible





**Thank you** for selecting miniBatt products.

Thank you for purchasing a miniBatt charging station. With this charger, you can charge any Qi-compatible device like a smartphone or other low-power wireless charging receivers without the hassle of untangling cables. Just place your smartphone on the charging surface, and your smartphone starts charging.

Parts of the product are magnetic. Metallic materials may be attracted to the charger. Do not place any credit card or other magnetic storage media near the product, because info stored on them may be erased.

**Read this user manual carefully before using the product.**

Also, read the user manual for the device that you connect to the charger.

Qi is a global standard that makes wireless charging possible for your device. With this a Qi-compatible device, you don't need to connect any cable to charge it.



Qi and Qi mark, are the trade marks of WPC.

**This product applies for all Qi standard transmitter.**





## PRODUCT INTRODUCTION:

**miniBatt PowerGOO** is a stylish, 3-coil Wireless PowerBank charger with a 6,000 mAh high-density battery to charge all kinds of wireless devices wherever you are. It also includes a twin USB output for charging devices with a standard connector.

Say goodbye to tangled wires and misplaced charging cables. Thanks to its exclusively designed silicone belt, you can charge your smartphone while carrying it into your bag.

## PRODUCT OVERVIEW:






## SPECIFICATIONS:

MAIN FUNCTION:	Wireless Charger + Power Bank
TYPE OF COIL:	3 Coils
Qi STANDARD:	Version 1.2
CHARGING METHOD:	One to One
INPUT:	DC5V / 2.0A
WIRELESS OUTPUT:	DC5V / 1.0A
USB OUTPUT 1:	DC5V / 1.0A
USB OUTPUT 2:	DC5V / 2.0A
BATTERY CAPACITY:	6.000 mAh
CHARGING DISTANCE:	6-8 mm.
EFFICIENCY RATE:	72%
WORKING FREQUENCY:	110-205KHz
DIMENSIONS:	153.3 x 82.8 x 13.7mm
BOX INCLUDES:	Wireless Charger, USB Cable, Manual Instructions





## INTRODUCTION OF BUTTON AND INDICATOR LIGHT:



## PARTS LIST (INCLUDED IN THIS PACKAGE):

- |  |       |
|--|-------|
| - Wireless Charger + Powerbank           | 1 PCS |
| - Micro USB to USB a digital cable 1,5 m | 1 PCS |
| - User Manual                            | 1 PCS |

## USER GUIDE:

### Switch on and charging

#### 1. Wireless charging when the charger plugged into a wall outlet:

1. Insert one end of USB charging cable into power adaptor (not included) (A) or to the computer (B).





**2.** Insert another end of USB charging cable into Micro USB port (5 PIN) jack of the wireless charger. The LED indicator lights up to indicate well connectivity.



press the power button

**3.** To turn on:  
Lightly press the power switch button to turn on the charger.  
The red light will be on.



**4.** Place your "Qi enabled Smartphone" on the charging pad. The blue LED light is blinking.

**5.** Long press the power switch for three seconds to turn off the Wireless Charging Function. Then the red light will be off.





## 2. Charging the Powerbank:

Insert one end of the USB charging cable into power adaptor (not included), and the other end to the Micro USB (5 PIN) jack. The blue LED light will flash continuously during charging. The indicator blue LED lights will be on after fully charged.



When the Powerbank is charged, you can bring it with you wherever you want to charge your smartphone!

Thanks to its exclusively designed silicone belt, the smartphone remains attached to the charger.

## 3. Wireless charging when the charger is not plugged into a wall outlet (using Powerbank):

### 1. To turn on:

Lightly press the power switch button to turn on the charger. The red light will be on.

2. Place your "Qi enabled Smartphone" on the charging pad. The blue LED light is blinking.

3. Long press the power switch for three seconds to turn off the Wireless Charging Function. Then the red light will be off.





## **SAFETY INFORMATION:**

- Keep the device dry. Precipitation, humidity and all types of liquids or moisture can contain minerals that corrode electronic circuits. If your device gets wet, allow the device to dry.
- Use the charging station for intended purposes only. Never use a damaged charger. The charging station should only be used at normal indoor conditions.
- Do not attempt to charge a device having a damaged, cracked or open battery case or a device that is not compatible with Qi.
- Do not use the device in dusty or dirty areas. Moving parts and electronic components can be damaged.
- Do not expose the device in high or low temperatures. The device can be damaged.
- Do not attempt to open , disassemble or dismantle the charger.
- Unauthorized modifications may damage the device and violate regulations governing radio devices.
- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and mechanics.
- Only use a soft, clean, dry cloth to clean the surface of the device.
- Please use suitable or compatible adapter to connect with the transmitting terminal.
- Please remove the protective layer before recharging.
- Please, do not charge your mobile phone when you charge the battery of the powerbank.
- Please long press the power switch three seconds to turn off power when you do not use wireless charge.
- Please stop using it immediately if battery is bulging, leaking or smelling.
- This product should be charged for once every month at lease when you do not use it for a long period.







## ADDITIONAL INFORMATION:

### Applicable devices:

- Devices with build-in wireless charging receiver.
- Devices with reserved wireless charging interface beside it battery.
- Devices with wireless charging receiver in its protection case.

### Note: All devices must be Qi Standard.

- Please use a 5V/2A adaptor and good quality cable to ensure charging effect.
- Please keep the charger away from water or other liquid.
- If you need to clean the charger, please make sure it is not connected to power supply.
- Working temperature: 0 ~ 45
- Working humidity: 10% ~80% (no vapor condense)

**Rubber belt included to fix the phone to the wireless charger when transporting.**





## **TROUBLESHOOTING:**

- 1.** If only one blue LED light is blinking, turn on the power switch. Otherwise battery will run down soon. Please recharge.
- 2.** If there is not any device on the charging pad, the charger will be disconnected automatically after 5 minutes.
- 3.** If the center point of the receiving terminal is deflected over 20 mm from the center point of transmitting terminal, the machine power will be off automatically. The more deflected, the more inefficiency.
- 4.** If the transmitting terminal detects that the current of load is over, it will disconnect connection automatically. The transmitting and receiving terminal will be kept standby status automatically. Reset receiving terminal and then restart.
- 5.** The charger will be disconnected automatically when it detects the load current is over.
- 6.** If you use incompatible adapter, the battery will be not fully charged, and the terminal will be damaged.





# MINI/BATT

## WARRANTY AND SUPPORT INFORMATION



Please register online  
[www.miniBatt.com/register](http://www.miniBatt.com/register)





**Thank you** for selecting miniBatt products.

## IMPORTANT!

Please register online: [www.miniBatt.com/register](http://www.miniBatt.com/register)

Please retain proof of purchase and warranty information.

To register your product, obtain product information and documentation, or to access customer-only special offers, direct your Web browser to the web page at:

**[www.miniBatt.com/register](http://www.miniBatt.com/register)**

Please retain the receipt as proof of purchase and write down the information below in case you need to obtain support information.

miniBatt Product Model:

Date of Purchase:

Hardware Serial Number:

Product Number:





## PRODUCT WARRANTY

**MINIBATT TECHNOLOGIES HK, LTD (“MINIBATT”)** offers a limited product warranty on hardware for two years from the date of purchasing.

Products repaired or replaced under warranty shall be subject to the product warranty remaining for the original products that are repaired or replaced.

Defects in material or workmanship on a hardware product or software, covered under warranty, will be repaired or replaced with the same or functionally equivalent product by **MINIBATT**, at its discretion, free of charge under these conditions:

- (1) Obtain a return material authorization (RMA) number from **MINIBATT**.
- (2) Return the failed product to a **MINIBATT** designated repair facility with shipping charge prepaid, and
- (3) Provide **MINIBATT** with written proof of the original date of purchase, such as a dated purchase receipt.

Replacement products may be refurbished or contain refurbished materials. If **MINIBATT**, by its sole determination, is unable to repair or replace the defective product, it will refund the purchase price of the product, less a reasonable usage charge.

This warranty does not apply if, in the sole judgment of **MINIBATT**, the product fails due to damage from shipment, handling, storage, accident, abuse or misuse, or if it has been installed, used or maintained in a manner not conforming to product manual instructions, has been modified in any way, or has had any serial number removed or defaced. Repair by anyone other than **MINIBATT** or an approved agent will void this warranty.

The maximum liability of **MINIBATT** under this warranty is limited to the purchase price actually paid by the customer for the product covered by the warranty, regardless of the amount of any other direct or indirect damage suffered by the customer. **MINIBATT**





makes no warranty that the software will be error free or will operate without interruption.

**MINIBATT** reserves the right to revise or update its products, software or documentation without notice. **MINIBATT** also reserves the right to change the terms of its limited product warranty at any time. Except as specifically provided above or as required by law, the warranties and remedies stated above are exclusive and in lieu of all others, oral or written, express or implied. Any and all other warranties, including implied warranties of merchantability and fitness for a particular purpose, and non-infringement of third party rights are expressly excluded. **MINIBATT** shall not under any circumstances be liable to any person for any special, incidental, indirect or consequential damages, including without limitation, damages resulting from use or malfunction of the product, loss of profits or revenues or costs of replacement goods, even if **MINIBATT** is informed in advance of the possibility of such damages. The maximum liability of **MINIBATT** under this warranty is limited to the purchase price actually paid by customer for the product covered by the warranty. Customer's purchase and usage of this product is expressly contingent upon the acceptance of the warranty terms above.



# MINI/BATT



For more information, please visit the  
miniBatt website: [www.miniBatt.com](http://www.miniBatt.com)



This device complies with CE regulations and meets the requirements of the applicable European guidelines.



Electronic old device are valuable materials and do not belong in the domestic waste. If the device has reached the end of its operational life, please dispose of it in accordance with the applicable regulatory requirements of the local collection points. Disposal in general household waste is prohibited.



The device is compatible with the WPC Standard Spec. 1.2 "Qi". Please only use the device with the Qi compatible devices.



Use only in dry indoors locations.

## Safety note:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

## Environmentally friendly disposal

Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collection point via private persons if for free. The owner of old appliances is responsible to bring the appliances to these collection points or to similar collection points. With this little personal effort, you contributed to recycle valuable raw materials and the treatment of toxic substances.



**miniBatt Technologies (HK) Ltd.**  
6/F, Oriental Crystal Commercial Building  
46, Lyndhurst Terrace, Hong Kong  
All rights reserved miniBatt ®



Designed in Barcelona  
Made in China